

Elbows



1

Pull both sides of the patch until the backing film separates at the center.



2

Remove the film on one side.



3

Keep the filmless part of the patch on hand.



4

Then apply its adhesive side to the elbow lengthwise.



5

Remove the remaining film by pulling it gently downward.



6

Press the patch gently all over for better adhesion.